



INSTALLATION SEQUENCE

1. ADHERE CHANNEL ISOLATORS TO SLEEPERS
2. PLACE CHANNEL ASSEMBLY PER CONSTRUCTION DRAWINGS/GUIDELINES
3. PLACE LOW DENSITY ACOUSTICAL ABSORPTION MATERIAL (OPTIONAL).
4. INSTALL FIRST LAYER OF PLYWOOD ACROSS CHANNELS OR SLEEPERS AND SCREW IN PLACE. BE SURE TO STAGGER SEAMS
5. COVER WITH OPTIONAL BUILDERS FELT
6. INSTALL SECOND LAYER OF PLYWOOD, CROSS LAPPING THE FIRST LAYER AND SCREW IN PLACE.
7. APPLY FINISH FLOOR PER MANUFACTURER

