



KNC RECOMMENDS THIS METHOD ONLY FOR PANELS THAT ARE PRIMARILY SUPPORTED BY OTHER MEANS (i.e TRIM, LEDGES, OTHER PANELS, FLOOR ETC.)

- DETERMINE WHERE PANELS ARE TO BE INSTALLED
- CLEAN WALL SURFACE AND APPLY CONSTRUCTION ADHESIVE TO PANEL BACK AS SHOWN IN DETAIL ABOVE
(ADHESIVE TO BE APPLIED TO FABRIC RETURN ONLY)
- NON-GREASY SCREWS OR NAILS CAN BE USED TO HOLD PANELS IN PLACE TEMPORARILY UNTIL ADHESIVE SETS UP (SEE ADHESIVE LABEL FOR CURE TIME)