



KNC RECOMMENDS THIS METHOD ONLY FOR PANELS THAT ARE PRIMARILY SUPPORTED BY OTHER MEANS ( i.e. TRIM, LEDGES, OTHER PANELS, FLOOR, ETC.)

- DETERMINE WHERE PANELS ARE TO BE INSTALLED
- CLEAN WALL SURFACE AND APPLY CONSTRUCTION ADHESIVE TO PANEL BACK AS SHOWN IN DETAIL ABOVE  
**(ADHESIVE TO BE APPLIED TO FABRIC RETURN ONLY)**
- NON-GREASY SCREWS OR NAILS CAN BE USED TO HOLD PANELS IN PLACE TEMPORARILY UNTIL ADHESIVE SETS UP (SEE ADHESIVE LABEL FOR CURE TIME)



TITLE  
INSTALLATION INSTRUCTIONS  
ADHESIVE ONLY

LAST DATE  
REVISED  
11-17-95

DRAWN BY  
DA

DRAWING NO. T-DWG  
INSTAL01.DWG