



1. USING APPROPRIATE SCREWS,  
ATTACH THE Z-CLIP TO THE WALL.  
(NOTE: HARDWARE SUPPLIED BY OTHERS)
2. POSITION KNP WALL PANEL ONTO  
Z-CLIP
3. ATTACH BOTTOM SUPPORT ANGLE



TITLE V-GROOVE KNP PANEL  
Z-CLIPS W/ SUPPORT ANGLES  
INSTALLATION INSTRUCTIONS

LAST DATE  
REVISED  
4/27/09

DRAWN BY  
JAA

DRAWING NO. T-DWG  
INSTALI6B.DWG