



ISOLATOR MOUNTING HOLES

INSTALLATION INSTRUCTIONS

1. JACK UP EQUIPMENT TO BE ISOLATED HIGH ENOUGH TO PLACE RD MOUNT UNDER EQUIPMENT MOUNTING BRACKETS.
2. ATTACH RD MOUNT TO EQUIPMENT MOUNTING BRACKET WITH BOLT AND WASHER (NOT INCLUDED). A NUT IS NOT NECESSARY AS THE EQUIPMENT MOUNTING HOLE IS THREADED. ROTATE RD MOUNT AS NECESSARY TO ENSURE ISOLATOR MOUNTING HOLES ARE ACCESSIBLE AFTER MOUNTING TO EQUIPMENT.

