



INSTALLATION:

1. DETERMINE WHERE PANELS ARE TO BE PLACED
2. CLEAN WALL AREAS WHERE ADHESIVE BACKING WILL CONTACT
3. JOIN HOOK AND LOOP VELCRO ON PANEL BACK. REMOVE BACKING FROM WALL-MOUNTED VELCRO. LOCATE AND PRESS PANEL FIRMLY ON WALL. (ALLOW ADHESIVE TO CURE BEFORE TRYING TO REMOVE PANEL FROM WALL)
4. KINETICS NOISE CONTROL DOES NOT RECOMMEND THIS MOUNTING METHOD WHERE WALL SURFACES ARE BLOCK, BRICK, OR CONCRETE

NOTES:

1. VELCRO STRIPS ARE TO BE PLACED ON FABRIC RETURN
2. HOOK AND LOOP VELCRO STRIPS ARE TO BE FIELD INSTALLED. CONTACT SALES DEPARTMENT FOR FACTORY INSTALLATION OPTIONS.