



- KNP-F  
INSTALLATION INSTRUCTIONS**
1. MARK BOTTOM OF PANEL ON WALL
  2. SCREW J-CHANNEL TO WALL WITH BOTTOM OF CHANNEL 1/8" BELOW MARK ON WALL
  3. PLACE PANEL INTO J-CHANNEL
  4. INSTALL Z-CHANNEL ON TOP OF PANEL AND FASTEN IN PLACE