



KNP-V INSTALLATION INSTRUCTIONS

1. MARK BOTTOM OF PANEL ON WALL.
2. SCREW J-CHANNEL TO WALL WITH BOTTOM OF CHANNEL 1/8" BELOW MARK ON WALL.
3. PLACE PANEL INTO J-CHANNEL
4. INSTALL Z-CHANNEL ON TOP OF PANEL AND FASTEN IN PLACE.