



LOCATE Z CLIPS ON WALL AND SECURE WITH SCREWS APPROPRIATE FOR WALL SUBSTRATE.

KSP INSTALLATION INSTRUCTIONS

1. USING APPROPRIATE SCREWS, ATTACH THE Z-CLIP TO THE WALL
2. MARK BOTTOM OF PANEL ON WALL
3. SCREW J-CHANNEL TO WALL WITH BOTTOM OF CHANNEL 1/8" BELOW MARK ON WALL
4. PLACE KSP PANEL INTO J-CHANNEL