

1. DRILL HOLES IN PANEL FRAME AS SHOWN
2. ATTACH OFFSET BRACKETS TO PANEL WITH 3/16" DIA. BOLT, NUT AND WASHER (BY OTHERS)
3. MOUNT PANEL ON WALL OR CEILING

