


Notes/Instructions:

1. After unit is set on curb, installer is to drill through unit base and curb wall with $\frac{1}{2}$ " diameter drill bit.
2. Install toggle bolt in $\frac{1}{2}$ " \varnothing hole with toggle in horizontal position.
3. Rotate bolt 180° until toggle drops to vertical position.
4. Tighten nut on toggle bolt.

INSTALLED SECTION VIEW

NO.	REVISION	DIMENSION TOLERANCE			TITLE	
0	Preliminary concept 5/1/19	\pm N/A			TOGGLE BOLT RESTRAINT BRACKET	
1	Through bolt concept 10/15/19		DIRECTORY:	DATE	DRAWN BY	DRAWING NO.
2	Through bolt concept revised			11/13/19	PJS	M-20190576
3	Bolt only option, no bracket 07/21/20					