

## Typical Panel to Structural Connections

Other connection methods available



Surface connection to HSS steel framing





Standard W-Column to Panel Connection Detail







kineticsnoise.com/noiseblock/ sales@kineticsnoise.com 1-800-959-1229

Manufacturing facilities in Ohio, USA; California, USA; and Ontario, Canada. Sales offices worldwide.