


INSTALLATION INSTRUCTIONS FOR SFH HANGER

- 1) LOCATE EACH HANGER INTO POSITION BASED ON SUBMITTAL DRAWING USING COLOR CODED SPRINGS AS IDENTIFICATION.
- 2) ATTACH HANGER BOX TO UPPER HANGING ROD AS SHOWN IN SKETCH.
- 3) ATTACH EQUIPMENT TO LOWER HANGING ROD AS SHOWN IN SKETCH.
- 4) IF NECESSARY, ADJUST EQUIPMENT LEVEL BY THE LEVEL ADJUSTMENT NUT ON THE TOP OF THE COIL SPRING AS SHOWN IN SKETCH.
- 5) CHECK TO ENSURE ADEQUATE ALIGNMENT BETWEEN THE LARGE HOLE IN THE HANGER BOX (AT THE BASE OF SPRING) AND THE LOWER HANGING ROD.



TITLE
 MODEL SFH HANGER
 INSTALLATION INSTRUCTIONS

LAST DATE
 REVISED
 9-27-06

REVISED BY
 BK

DRAWING NO.
 INS-03.35-1A

INS-03