

Recommended Cleaning Guidelines for HealthGuard Acoustical Panels

Frequent vacuuming or light brushing is recommended to remove dust and grime. May be cleaned with a 10:1 water-to bleach solution. Rinse well after cleaning. Oil and grease type spots will respond to mild solvent or dry-cleaning agents. When spot cleaning with either of those agents, follow instructions carefully and clean only in a well-ventilated area. Avoid any product which contains carbon tetrachloride or other toxic materials. The blotting technique (without rubbing) should be sufficient to remove most oil and grease type spots.

Notes:

1. Kinetics recommends pre-testing a small area before proceeding to spot clean the fabric with any cleaning agent.
2. If panels get water stains from an excessive amount of water, there is not a cleaning agent that will remove a water stain. Kinetics would recommend replacing the panels.