

## KCI-A Installation Instructions

1. Locate each KCI-A Isolator as specified on the Submittal Drawing.
2. Align the equipment.
3. Mark the Isolator Housing attachment locations.
4. Raise the equipment and install the Isolator Housing attachment anchors or fasteners.
5. Lower the equipment and fasten to Attachment Angle.
6. Adjust the KCI-A Isolator by turning the Leveling Nut 1 to 2 turns clockwise.
7. Repeat turning the Leveling Nut 1 to 2 turns clockwise on each isolator until the gap between the Isolator Housing and Rubber Snubber faces is equal on the top and bottom.
8. Do not move the KCI-A Isolators laterally with the weight of the equipment on them. Raise the equipment to remove the weight from the KCI-A Isolators before moving

