

IMPORTANT

KINETICS NOISE CONTROL DOES NOT RECOMMEND THE USE OF COATED AIRCRAFT CABLE. IF COATED CABLE IS USED, THE COATING MUST BE STRIPPED AT POINTS OF CLAMPING.

SUGGESTED INSTALLATION INSTRUCTIONS FOR OVATION REFLECTOR PANELS

- ATTACH 1/8" AIRCRAFT CABLE TO CEILING STRUCTURE AT APPROXIMATE LOCATIONS OF SUSPENSION POINTS ON PANELS.
- 2. FASTEN CABLE TO ITSELF USING CABLE CLAMPS AND THIMBLES (BY OTHERS).
- 3. ALLOW CABLE DROPS OF SUFFICIENT LENGTH TO ATTACH TO REFLECTOR PANELS THROUGH SUSPENSION HOLES.
- 4. HOIST REFLECTOR PANEL INTO POSITION. THREAD CABLE THROUGH EYEBOLTS AND FASTEN TO ITSELF USING CABLE CLAMPS AND THIMBLES (BY OTHERS).
- 5. PANEL WEIGHT APPROXIMATELY 3 LBS./SQ. FT.



TLE SUGGESTED INSTALLATION
INSTRUCTIONS FOR GEL COAT
OVATION REFLECTOR PANELS

LAST DATE REVISED

12/22/17

DRAWN BY

DICTO

DRAWING NO. T-DWG

DQK

INSTALL42