

NOTE:

THE ENGINEER OF RECORD FOR THE PROJECT MUST PROVIDE, OR REVIEW AND APPROVE, THE INSTALLING CONTRACTOR'S METHOD OF CONNECTING THE ACOUSTICAL PRODUCTS TO THE BUILDING STRUCTURE

SUGGESTED INSTALLATION INSTRUCTIONS FLAT OVATION REFLECTOR PANELS

- 1. ATTACH 1/8" DIA. AIRCRAFT CABLE TO CEILING STRUCTURE AND FASTEN TO ITSELF USING CABLE CLAMPS (BY OTHERS).
- 2. ALLOW EXCESS AMOUNTS OF CABLE TO HANG DOWN AT EACH LOCATION TO ATTACH TO REFLECTOR PANEL.
- 3. HOIST PANEL INTO POSITION.
- 4. THREAD AIRCRAFT CABLE THRU RESPECTIVE HOLE AND FASTEN CABLE TO ITSELF USING CABLE CLAMPS (BY OTHERS).
- 5. PANEL WEIGHT APPROXIMATELY 3 LBS / SQ. FT.

Noise Control

SUGGESTED INSTALLATION INSTRUCTIONS FOR FLAT OVATION REFLECTOR PANELS LAST DATE **REVISED**

DRAWN BY

DRAWING NO.

T-DWG

DQK

INSTALL43

12/22/17