



STRUCTURAL NOTE:
STRUCTURAL SLAB F- NUMBERS
F_f - FLOOR FLATNESS NUMBER
SPECIFIED OVERALL VALUE = 38
MINIMUM LOCAL VALUE = 25

LIFTING NOTES:
CONCRETE MUST CURE TO DESIGN STRENGTH. AFTER CURING, RAISE SLAB BY CAREFULLY DRIVING LIFTING SCREWS. DRIVE EACH SCREW 2 OR 3 TURNS (MAX) IN SEQUENCE UNTIL DESIGN OPERATING HEIGHT HAS BEEN REACHED. DO NOT DRIVE INDIVIDUAL SCREWS MORE THAN 2 OR 3 TURNS, OR TURN THEM OUT OF SEQUENCE. DOING SO MAY CAUSE DAMAGE TO CONCRETE OR ISOLATOR.
TURNING IN EXCESS OF 2 TO 3 TURNS MUST BE APPROVED BY STRUCTURAL (CONCRETE) ENGINEER.

DIMENSION FORMAT: IN (mm)

SCALE: NTS



LSM ISOLATED SLAB:
INSTALLATION SEQUENCE

Revised
6/14/2018

Drawing No.
AA001786

kineticsnoise.com/lsm